


TEL1C* Series

Sensor Faucet, Libella™ Wall-Mount Spout EcoPower® Self Generation System



Item	Part	Description
All Models		
1	THP3181	Bracket, Wall Mount, Libella
2	THP3182	Set Screw
3	THP3183	Anchor (1 pc)
4	THP3184	Screw (1 pc)
5	THP3152	Hose
6	THP3153	Clip (1 pc)
7	THP3155	Sensor
8	THP3174	Aerator housing
9	THP3175	Nut
10	THP3176	Screw (1 pc)
11	THP3178#CP	Cover, nozzle area
12	THP3177	Aerator (1.0 gpm)
	THP3124	Aerator (0.5 gpm)
	THP3311	Aerator (0.35gpm)
13	THP3304#CP	Aerator Kit, (0.35 gpm)
13.1	THP3302	Fastener (0.35gpm)
13.2	THP5100	Gasket
13.3	THP3242	O-Ring
13.4	THP3299#CP	Housing (0.35 gpm)
14	THP3179	Aerator Removal Key (1.0 gpm/0.5 gpm)
	THP3305	Aerator Removal Key (0.35 gpm)
C1	TH559EDV562	Generator for TELC105-D10E, TELC105-C20E
	TH559EDV462	Generator for TELC101-D10E
	THP3275	Generator for TELC103-D20E
C2	THP3132	O-ring (1 pc)

Item	Part	Description
C3	THP3107	Spacer, Gene & Solenoid
C4	THP3106	C-Clip, Gene & Solenoid
C5	THP3323	Solenoid Valve Unit
C6	THP4115	O-ring (1 pc)
C7	THP3112	Mount Bracket
C8	THP3111	Strainer
C9	THP3102	Adaptor, Supply in
C10	THP3101	Large Nut for Mount
C11	THP3113	Case
C12	THP3053	Backup Battery (Lithium) (1 pc)
C13	THP3096	Controller for TELC105-D10E, TELC101-D10E
	THP3114	Controller for TELC105-C20E
	THP3274	Controller for TELC103-D20E
C14	THP3105	Cover, Controller
C15	THP3098	Cover
C16	THP3099	Screw for Cover
C17	THP3109	Quick Fastener
C18	THP4485	Screw (1 pc)
C19	THP3272	Flow Regulator Adapter and Gasket for TELC103
C20	THP3276	Extension Harnesses (2 types per bag)
T1	TLE05701U	Thermostatic Mixing Valve (for min 0.35 gpm)
	TLT20	Thermostatic Mixing Valve (0.35 gpm)
T2	TLM10	Hot/Cold Mixing Tee
T3	THP5084	TLT10(R) Mounting Bracket
T4	THP3237	TLT10(R) / TLT20 Swivel Coupling
T5	THP3243	Gasket (2 pc)